SKU: 045588

# DYNAMIC LINE ROMAN CHAIR

**USER MANUAL** 



It is with great pleasure that we offer you the opportunity, guidance and encouragement to practice aerobic and muscular exercises, getting like this, the physical preparation needed to feel good. We guarantee a reliable and modern product, produced with high technology for people who care about their well-being.

This manual covers the main information, the basic structure and the main operation and preventive maintenance. It will help you familiarize yourself with all the equipment functions, for you enjoy it for a long time.



Carefully read the safety and usage guidelines contained herein. Follow the guidelines for correct assembly of the product. **Caution:** Do not push any objects into the openings of the product. Stay clear of moving parts.

Safety and security: it is the owner's responsibility to ensure that all users are properly informed about safety precautions, use, maintenance and care of the product.



Inappropriate use for children and animals.



# **CONTENTS**

# english

| COMPONENTS AND TECHNICAL SPECIFICATIONS | 4  |
|---|----|
| SPARE PART LIST                         | 5  |
| ASSEMBLY                                | 7  |
| PREVENTIVE MAINTENANCE                  |    |
| WARRANTY                                | 14 |

# **COMPONENTS AND TECHNICAL SPECIFICATIONS**



| Product                  |        | Packaged            |        |  |
|--------------------------|--------|---------------------|--------|--|
| Net weight (approximate) | 57Kg   | Gross weight        | 62Kg   |  |
| Maximum width            | 835mm  | Width (carton box)  | 1010mm |  |
| Maximum length           | 1275mm | Height (carton box) | 360mm  |  |
| Maximum height           | 880mm  | Lenght (carton box) | 580mm  |  |

## **SPARE PART LIST**

|       | Parts list (Individually packaged) |       |                                    |          |                               |  |  |  |  |  |
|-------|------------------------------------|-------|------------------------------------|----------|-------------------------------|--|--|--|--|--|
| 2     |                                    |       | • • •                              |          |                               |  |  |  |  |  |
| NO.1  | 07 Foot welding set*1              | NO.2  | Rear foot pipe set*1               | NO.3     | Front ground leg set*1        |  |  |  |  |  |
|       |                                    |       |                                    | <b>=</b> | mm)                           |  |  |  |  |  |
| NO.4  | 03 Support frame welding group*1   | NO.10 | 04 Connecting pipe welding group*1 | NO.11    | 05 Adjustment welding group*1 |  |  |  |  |  |
|       | (O)                                |       |                                    | 0        |                               |  |  |  |  |  |
| NO.12 | 2004 Aluminum Flat End<br>Caps*6   | NO.13 | 2007 Nylon column*2                | NO.14    | 2007 Galvanized spindle*2     |  |  |  |  |  |
| F     |                                    |       |                                    |          |                               |  |  |  |  |  |
| NO.19 | 06 Assistant handrail*1            |       |                                    |          |                               |  |  |  |  |  |
|       |                                    |       |                                    |          |                               |  |  |  |  |  |
|       |                                    |       |                                    |          |                               |  |  |  |  |  |
|       |                                    |       |                                    |          |                               |  |  |  |  |  |
|       |                                    |       |                                    |          |                               |  |  |  |  |  |
|       |                                    |       |                                    |          |                               |  |  |  |  |  |

|   | Blister pack screw schedule     |   |  |   |  |  |  |  |  |
|---|---------------------------------|---|--|---|--|--|--|--|--|
|   |                                 |   |  | ( |  |  |  |  |  |
| А | M10*95 flat round head screws*4 | В | Φ10 flat washer*18                       | С | M10 lock nut*9                           |  |  |  |  |
|   |                                 |   |  |   |  |  |  |  |  |
| D | M10*70 flat round head screws*3 | G | M10*25 flat countersunk<br>head screws*4 | н | M10*40 flat countersunk<br>head screws*2 |  |  |  |  |
|   |                                 |   |  |   |  |  |  |  |  |
| К | M8*25 half round head screws*2  |   |  |   |  |  |  |  |  |
|   |                                 |   |  |   |  |  |  |  |  |
|   |                                 |   |  |   |  |  |  |  |  |
|   |                                 |   |  |   |  |  |  |  |  |
|   |                                 |   |  |   |  |  |  |  |  |
|   |                                 |   |  |   |  |  |  |  |  |
|   |                                 |   |  |   |  |  |  |  |  |
|   |                                 |   |  |   |  |  |  |  |  |
|   |                                 |   |  |   |  |  |  |  |  |


## **ASSEMBLY**




**NOTE:** Place the packaging with the equipment on a level surface. It is recommended that you place a protective cover for your door. Exercise caution when you are loading and transporting equipment. Unpack and assemble the equipment where it will be used. If necessary, ask the help of someone else.

# STEP 1


| Item NO | Name                              | Qty | Item NO | Name                             | Qty |
|---------|-----------------------------------|-----|---------|----------------------------------|-----|
| NO.1    | 07 Foot welding set               | 1   | А       | M10*95 flat round head<br>screws | 4   |
| NO.2    | Rear foot pipe set                | 1   | В       | Φ10 flat washer                  | 14  |
| NO.3    | Front ground leg set              | 1   | С       | M10 lock nut                     | 7   |
| NO.4    | 03 Support frame<br>welding group | 1   | D       | M10*70 flat round head<br>screws | 3   |



|         | 07 Foot welding set*1 |     |         |                                      |     |  |  |  |  |
|---------|-----------------------|-----|---------|--------------------------------------|-----|--|--|--|--|
| Item NO | Name                  | Qty | Item NO | Name                                 | Qty |  |  |  |  |
| NO.5    | 0004 Foam Covers      | 2   | NO.8    | Q1006-1009 square<br>pipe plug 50*75 | 3   |  |  |  |  |
| NO.6    | 0005 Foam roller F4   | 2   | E       | Q1006-1009 square<br>pipe plug 50*75 | 2   |  |  |  |  |
| NO.7    | 0003 foam barrel lid  | 2   | F       | 2018 Star nut M10                    | 2   |  |  |  |  |




| NO.2 Rear foot pipe set*1 |                                   |                                |   |  |  |  |  |
|---------------------------|-----------------------------------|--------------------------------|---|--|--|--|--|
| Step NO                   | Item NO Name Qty Item NO Name Qty |                                |   |  |  |  |  |
|                           | NO.9                              | Q1003-2001 50*75 foot<br>cover | 2 |  |  |  |  |




# NO.3 Front ground leg set\*1


| Item NO | Name                        | Qty | Item NO | Name | Qty |
|---------|-----------------------------|-----|---------|------|-----|
| NO.9    | Q1003-2001 50*75 foot cover | 2   |         |      |     |




# STEP 2

| Item NO | Name                                | Qty | Item NO | Name                            | Qty |
|---------|-------------------------------------|-----|---------|---------------------------------|-----|
| NO.10   | 04 Connecting pipe<br>welding group | 1   | G       | M10*25 flat<br>countersunk head | 4   |
| NO.11   | 05 Adjustment welding group         | 1   | н       | M10*40 flat<br>countersunk head | 2   |
| NO.12   | 2004 Aluminum Flat End<br>Caps      | 6   |         |                                 |     |
| NO.13   | 2007 Nylon column                   | 2   |         |                                 |     |
| NO.14   | 2007 Galvanized spindle             | 2   |         |                                 |     |






| NO.10 Connecting pipe welding group*1 |                              |     |         |                                   |     |  |  |
|---------------------------------------|------------------------------|-----|---------|-----------------------------------|-----|--|--|
| Item NO                               | Name                         | Qty | Item NO | Name                              | Qty |  |  |
| NO.15                                 | 2013 Polypropylene<br>Spacer | 4   | NO.16   | 2004 Deep Groove Ball<br>Bearings | 4   |  |  |





| N       | NO.11 05 Adjustment welding group*1 |     |         |                |     |  |  |  |
|---------|-------------------------------------|-----|---------|----------------|-----|--|--|--|
| Item NO | Name                                | Qty | Item NO | Name           | Qty |  |  |  |
| NO.17   | Cushion                             | 2   | J       | Φ8 flat washer | 8   |  |  |  |
| 1       | M8*25 half round head screws        | 8   |         |                |     |  |  |  |



# STEP 3


| Item NO | Name                  | Qty | Item NO | Name                            | Qty |
|---------|-----------------------|-----|---------|---------------------------------|-----|
| NO.19   | 06 Assistant handrail | 1   | С       | M10 lock nut                    | 2   |
| В       | Φ10 flat washer       | 4   | К       | M8*25 half round head<br>screws | 2   |





# NO.19 Assistant handrail\*1

| Item NO | Name                        | Qty | Item NO | Name                                  | Qty |
|---------|-----------------------------|-----|---------|---------------------------------------|-----|
| NO.20   | 0218 Aluminum locking cover | 2   | L       | 2017 Star nut M8                      | 2   |
| NO.21   | Φ25 Rubber                  | 2   | М       | M8*25 flat countersunk<br>head screws | 2   |
| NO.22   | 2010 Aluminum End Caps      | 2   | N       | M5*6 tight-fitting<br>screws          | 4   |



## PREVENTIVE MAINTENANCE

Before you use your equipment make sure it is in good condition. Check the general condition of the equipment, as described in "Safety Information". If the equipment is not in perfect condition, contact an Authorized Technical Assistant.

#### **CLEANING:**

- · Never use abrasive or solvents for cleaning.
- Do not leave the equipment exposed to natural agents such as sunlight, rain, dew, dust, salt spray etc.
- Do not put the equipment in dusty environments, wet, saunas or anywhere unventilated.
- Always use original spare parts. Improper maintenance can cause damage to the product and loss of warranty.
- If you prefer, this cleaning can be done by a Technical Assistant (see values).

### WARRANTY

#### Terms of Guarantee

A. The warranty procedures will be carried out only upon presentation of the note / original coupon tax of Sale and limitations laid down by these Terms. The guarantee shall be provided by the Authorized Technical Assistance Network.

B. The conditions set out in this Agreement are guaranteed to the first user purchaser of this product for a period of 6 (six) months (including the legal guarantee period - first 90 (ninety) days, counted from the date of issuance of the note / tax Coupon sale, in the event of exclusively residential use.

C. Warranty and coverage terms start to count from the date of issue of the sales invoice / coupon, including the legal term of 90 (ninety) days.

# PARTS AND COMPONENTS Structure 10 years 10 years 10 years 10 years 10 years 11 year 1

- D. Parts repaired or replaced under this warranty does not stop nor extend the warranty period originally stipulated.
- E. To be used by this warranty, the equipment must have been installed by authorized technical assistant, except for residential products.
- F. Warranty does not cover the installation and preventive maintenance services such as cleaning, lubrication and adjustment of the product.
- G. No dealer is authorized to receive client product to refer you local dealer or this take it to return to it and to provide information on behalf of the Manufacturer / Supplier of the progress of the service. The manufacturer / supplier or consumer support are not responsible for any damage or delay due to this non-compliance.
- H. The Manufacturer / Supplier keep available spare parts until they cease the manufacture or import the equipment. If it ceased the production or import of equipment Manufacturer / Supplier keep the spare supply its line of equipment for a reasonable period of time, according to the law.
- I. Within the period of thirty (30) days if the equipment presents some malfunction, the customer may choose to take the product to an authorized posts or requesting service in your home without travel expenses in those counties covered by the Network Authorized Service. After the period of thirty (30) days or in municipalities not covered by the Technical Assistance Network Authorized expenses resulting from any transport of the equipment to a freight service, removal or technical visit by tecnical assistent.

occur by the customer, whether or not this equipment covered by this warranty.

J. Lubricants, silicones for equipments, vaseline to the guide weights and micro oil to the joints of weight stations, should be exclusively recommended by the manufacturer, available at Authorized Technical Assistance Network.

K. Components that wear out with regular use of equipment such as motor brushes, belts, pads, brake bands, felt, steel chains and cables, when this equipment will have warranty for a period of 90 days from the invoice or manufacturing defect found by the Authorized Technical Assistance Network.

#### **Extinction Assurance**

This warranty will be considered void when:

A. Expiry of the warranty term.

B.Equipment repaired by a person not authorized by the Manufacturer / Supplier, if signs of violation of its original characteristics or non-factory assembly are found.

C. Damage suffered by the equipment due to improper use, use of inappropriate cleaning products, oxidation from external agents, wear, neglect, modification, use of accessories not recommended, inadequate design for the intended application, falls, perforations, use and opposite installation to the operating instructions, inadequate wiring in the electrical network, lack of grounding in badly sized grids and / or excessive fluctuations and overloads.

D. For residential line is prohibited any type of user equipment maintenance or a third party other than the technical assistance network

E. The product is used in gyms, condominiums, clinics, clubs, sauna, submerged in water or use so that it resembles other than for residential purpose or the application of the purpose intended.

#### Comments:

A. cables, carabiners, pedals when existing in the product should be replaced once a year.

B. The Manufacturer / Supplier is not responsible for any accidents and their consequences, arising from breach of the original features or assembly out of their equipment factory default.

C. Customer's responsibility are those resulting from unfounded judged answering calls.

**Note:** Manufacturer / Supplier reserves the right to make changes without notice this.

# Athletic